




The Product

- Stops and locks into place automatically at desired depth
- The Suremarker is made with the highest grade plastics and PVC.
- Prevails in harsh salt water and sun conditions.
- Fast Deployment – No back lash.
- Anchoring aid – The highly visible flag indicates wind direction.
- Easily retrieved with the patented clicker reel.
- Portable – fits in most rod holders and rocket launchers.
- One year limited warranty.



Ease of Use

- The lightning speed of deployment, balanced with the precise depth locking system assures your spot to be within inches of the Suremarker. No missed marks!
- Accurate deployment of the Suremarker is easy. Simply remove the crank handle, throw the Suremarker overboard using a 4 to 4-1/2 lb. weight affixed to the line and the automatic release will do the rest.
- Set your anchor, drift back to your spot, and start your dive.
 - To retrieve, simply gaff the Suremarker underneath the float. Use wrist cord while attaching the crank handle, and reel in.
 - Replacement parts available, please visit www.suremarker.com

Product Specifications

- Premium cloth flag.
- Highly visible float and flag.
- High density PVC foam float.
- 100 lb. braided nylon line.
- Detachable crank handle with lanyard.
- Tuff ABS plastic, T-Grade™.



8000 Fruitville Road
Sarasota FL 34240

Tel. (941) 379-0533 Fax. (941) 379-8320

Web: www.suremarker.com Email: info@suremarker.com